


VEKTA.5 V3 REAR AXLE INSTALLATION FOR VEKTA.5 AND VEKTA.5TT



For a complete guide on the differential installation and set-up, please refer to HARDWARE the primary kit manual KT5609 -REAR DIFF OUT DRIVE KT5610 - REAR DIFF OUT COLLAR

